

## *RV10 jackpoint installation instructions*

- 1. Remove your main gear wheel pants.*
- 2. Jack your RV10 (for the last time) up high enough to the Remove Main wheel assy.*
- 3. Remove the two aft upper and lower bolts holding your brake caliper bracket and wheel pant bracket, Replace them with the supplied An4-17A bolts "INBOARD TO OUTBOARD"*
- 4. Add the supplied spacer to the aft bolt that had no spacer.(see photo)*
- 5. Install the jackpoint base mount.*
- 6. Adjust as necessary your brake line to accept the jack Arm and pin installation for jacking*

### *NOTE#*

*We used different Jacks for testing the Jackpoints and found the Harbor Freight Alum floor jack and their Screw jack to work the best. In fact I carry a screw jack in mt RV tool bag. Here are the Part numbers:*

*Screw Jack:SKU# 66907 sells for about \$19.99*

*Alum floor jack SKU# 62160 sells for about \$89.99*

