

RV14A jackpoint installation instructions

- 1. Remove your main gear wheel pants.*
- 2. Remove the two aft inboard Wheel pant mount brackets*
- 3. Mark center of bracket and using a "UniBit" drill out a 7/8" hole and deburr.*
- 4. Install the jackpoint mount to ensure proper fit.*

NOTE#

We used different Jacks for testing the Jackpoints and found the Harbor Freight Alum floor jack and their Screw jack to work the best. In fact I carry a screw jack in mt RV tool bag. Here are the Part numbers:

Screw Jack:SKU# 66907 sells for about \$19.99

Alum floor jack SKU# 62160 sells for about \$89.99

